



The mitre is pre-cut and the necessary fasteners for joining left and right hand mitre sections are supplied with each mitre. Mitre sections should be joined together before installation on cabinet. Follow these steps:

1. If it is necessary to cut a mitre section down to a specific length, always cut from square end.
2. Apply bead of waterproof glue to each mitre edge.
3. Place fasteners in position (Fig. 1) and tighten only enough to fold fasteners in place.
4. Match the front edges and tighten the nearest fastener.
5. Check seam where backsplash sections join. If flush, tighten the nearest fastener. Use a 1 1/4" nail (Fig. 2) and toenail the backsplash sections.
6. If entire seam is level, tighten the two remaining fasteners. If one section is higher than the other, place a wood block on raised area and strike lightly with a hammer or mallet to level the 2 sections. **DO NOT STRIKE THE AREA IMMEDIATELY OVER FASTENING BOLTS.** Then secure as they will fall out of place until they are tightened.

Please note: If your cabinets are not level when you are assembling the mitre it will be very difficult for you to line the tops up and get a nice level seam.